




SAVOY

SWISS MADE

Swiss made RONDA 4220B instructions & warranty information for SAVOY MIDWAY GMT collection



WWW.SAVOYWATCHES.COM

INTERNATIONAL WARRANTY

- 1) The warranty card is only valid when filled by an authorized SAVOY dealer and activated online at www.SavoyWatches.com.
- 2) The warranty is for two years from the date of purchase. The warranty covers manufacturers defects only. The warranty does not cover batteries, water damage to the watch and movement due to improper use, broken crystals, damaged or faded straps, lost screws, crowns, cases, or plating. Damage to any part of the watch through normal wear and tear or by accident is not covered under this warranty.
- 3) The warranty is void when any repair or work to the watch is done by a non authorized SAVOY dealer. Services are not covered by the warranty and are subject to additional charges including, but not limited to, battery changes and waterproofing.

WELCOME

Thank you very much for your SAVOY purchase. Congratulations, as you are now one of the selective customers that owns an exclusive and distinctive SAVOY timepiece.

Enjoy it every minute!

Remember now to register your SAVOY watch online to validate the international warranty. This will establish you as the exclusive owner and will enable us to provide our loyal customers with better service. All information received will remain confidential.

Please follow us on social media @savoywatches to receive the latest news and product information.


ICON MIDWAY GMT

Origin:	Swiss made mechanism and manufacturing.
Case:	41mm stainless steel (316L), PVD black or IP plating.
Movement:	Swiss Made Ronda 4220B with second time zone (GMT) function and big day date.
Dial:	2 eyes design with sunray pattern and brushed minute track. Hour and minute hands Superluminova.
Crystal:	Sapphire crystal with 5 anti-reflective coatings.
Strap:	High grade interchangeable rubber, genuine leather or stainless steel (316L) metal bracelet with patented screwed inserts system when available.
Buckle:	Stainless steel custom made deployment buckle with push button release with logo.
Water resistance:	10 ATM, 100 m, 330 ft.
Warranty:	2 years international

Description of the display and control buttons


Display elements

4210.B




Display elements

4220.B




Caution: Make always sure that the crown is in the screw-in position in order to ensure the water resistance of the watch.

Pushbuttons and crown should never be operated under water.




Setting the time

- 1 * Pull out the crown to position III (the watch stops).
- 2 Turn the crown until you reach the correct time 8:45.
- 3 * Push the crown back into position I.




Please note:

* In order to set the time to the exact second, **1** must be pulled out when the second hand is in position «60». Once the hour and minute hands have been set, **3** must be pushed back into position I at the exact second.



Setting the date (quick mode)


- 1 Pull out the crown to position II (the watch continues to run).
- 2 Turn the crown until the correct date **01** appears.
- 3 Push the crown back into position I.




Please note:

During the date changing phase between approx. 9 PM and 12 PM; the date must be set to the date of the following day.

An extreme acceleration in setting the date with quick mode can induce a false date indication. The synchronization is re-established by setting the date from 01 till 31 (crown in position II).




- 3* Pull out the crown to position III (the watch stops).
- 4 Turn the crown until the correct date **04** appears.
- 5** Continue to turn the crown until the correct time 8:30 PM appears.
- 6 Push the crown back into position I.



Please note:

- * To set your watch to the exact second, please refer to the chapter entitled «setting the time».
- ** Please observe the AM/PM clock rhythm.

Setting the 2nd time zone



Any 2nd time zone can be set using the small hour hand and small minute hand.

- 1 Activation:** Press the push button for at least 2 seconds.
As soon as the small minute hand jumps forward one minute, this mode of operation is activated.
- 2 Brief pressing:** (less than 1 second)
Moves forward individual minutes.
Medium pressing: (1 to 2 second)
Moves forward 1 hour.
Long pressing (longer than 2 seconds)
The time zone is moved forward until the push button is released.

Please note:

If the push button is not pushed for ten seconds, the setting mode is deactivated. Please see point no **1** for activation.

CUSTOMER SERVICES

AMERICAS

info@savoywatches.com
T +1 754 300 5141

Consumer Repairs Americas
Swiss Watchmakers & Company
17616 Collins Avenue
Sunny Isles Beach
Florida, FL 33160

ASIA

info@savoywatches.com
T +852 (2713) 3701

Consumer Repairs Asia
Furtune Concept
1/FL Goldsland Bldg.
22-26 Minden Ave.
TST, Kowloon
Hong Kong

EUROPE

info@savoywatches.com
T +41 (61) 561 42 00

Consumer Repairs Europe
Tick Tack AG
Industriestrasse 5
4313 Moehlin
Switzerland

MIDDLE EAST

info@savoywatches.com
T +971 4 299 6999

Consumer Repairs Middle East
Swiss Watch Group FZCO
PO BOX 54252 Dubai
United Arab Emirates

Facebook.com/SavoyWatches
@savoywatches

info@savoywatches.com
+1 754 300 5141

www.savoywatches.com